



Operating Mode

View Counts

1. Press F1 to scroll flow meters;
2. Control will display normal counts for selected flow meter;
3. Pressing F1 again will show special period counts (if enabled);
4. Continue scrolling to view other flow meters.

Print Counts

1. Scroll with F1 to flow meter to print;
2. Press F2 to print selected flow meter;
3. To print all flow meters, press F2 when the “Idle Screen” is displayed.

Enter Manager Menu

1. Press F3;
2. Swipe manager key;
3. To scroll items, press F1;
4. To select items, press F2;
5. To cancel manager menu, press F3 again.

Manager Menu

Manager menu options:

- Clear Counters;
- Calibrate;
- Flow Mode;
- Period;
- Time;
- Network;
- Manager key's

Clear Counters

This option enables you to reset all or specific flow meter(s) counts.

1. Scroll flow meter with F1, select with F2;
2. The control will ask for your confirmation before proceeding. Press F1 to accept or F2 to cancel;
3. If you accepted, the control will confirm that the action has been done. Press F1/F2 to go back in manager menu.



Calibrate

This option enables you to adjust the quantity poured for the portion you need when the flow meter is in portion mode, and let's you adjust the number of pulse needed when the control is in ounce mode.

1. Scroll flow meter with F1, select with F2;
2. If flow meter is in portion mode:
 - a. Pour desired quantity on the selected flow meter;
 - b. When done, press F1;
 - c. The control will ask for your confirmation before proceeding. Press F1 to accept, F2 to cancel;
 - d. If you accepted, the control will confirm that the action has been done. Press F1/F2 to go back in manager menu.
3. If flow meter is in ounce mode:
 - a. Press F1 to increment, F3 to decrement pulse value;
 - b. When done, press F2
 - c. The control will ask for your confirmation before proceeding. Press F1 to accept, F2 to cancel;
 - d. If you accepted, the control will confirm that the action has been done. Press F1/F2 to go back in manager menu.

Flow Mode

This option enables you to set a flow meter in ounce or portion mode. Ounce mode counts every ounce poured while portion mode counts every portion poured. (Portion are adjusted has you need. See Calibrate menu option.)

1. Scroll flow meter with F1, select with F2
2. The current mode of the flow meter is now displayed. To toggle modes, press F1. When done, press F2
3. The control will ask for your confirmation before proceeding. Press F1 to accept or F2 to cancel;
4. If you accepted, the control will confirm that the action has been done. Press F1/F2 to go back in manager menu.

Period

This option enables you to separate counts in two periods. When enabled, all the counts in the defined period will be in the “Special” counters, while all the rest of the counts outside the period will be in the “Normal” counters.

1. Press F1 to toggle period state;
2. If period is enabled, the control will ask you if you want to modify the period. To modify, press F1. To return to menu, press F2
3. To modify the period time, pressing F1 increments the current value on the cursor, F2 moves to the next field.
4. When at the end of all fields, the control will ask for your confirmation before proceeding. Press F1 to accept, F2 to cancel;
5. If you accepted, the control will confirm that the action has been done. Press F1/F2 to go back in manager menu.

Time

This option set's current time.

1. The control will ask you if you want to modify time. To modify, press F1. To return to menu, press F2;
2. To modify time, press F1 to increment the current value on the cursor, F2 moves to the next field;
3. When at the end of all fields, the control will ask for your confirmation before proceeding. Press F1 to accept, F2 to cancel;
4. If you accepted, the control will confirm that the action has been done. Press F1/F2 to go back in manager menu.

Network

This option set the control networks address when then control is used in a RS485 network.

1. The control will ask you if you want to modify the address. To modify, press F1. To return to menu, press F2;
2. Press F1 to increment network address. When done press F2;
3. The control will ask for your confirmation before proceeding. Press F1 to accept, F2 to cancel;
4. If you accepted, the control will confirm that the action has been done. Press F1/F2 to go back in manager menu.



Manager Key's

This option let's you add/change manager key.

1. Swipe first manager key;
2. Swipe second manager key;
3. The control will ask for your confirmation before proceeding. Press F1 to accept, F2 to cancel;
4. If you accepted, the control will confirm that the action has been done. Press F1/F2 to go back in manager menu.

Exit

Exit manager menu and return to normal mode.

Note-1: While in manager menu, pressing F3 in any menu will exit manager menu.

Note-2: While in manager menu, PC communication is disabled.